

Old Work

- 1 Cut 3-3/8" x 6" hole next to stud.
- 2 Install NM cable connector (supplied). Pull wire. Mount box to stud with (2) #8 x 3" screws (supplied) through the angled holes in the outer edge of the box. Use positioning tabs (see detail below) to allow for drywall thickness.
- 3 Wire in receptacle.
- 4 Attach trim plate with (2) #6 x 1/2" screws (supplied).



New Construction

