

For example, if French is selected as the language and you repeatedly press the letter **a**, you will see **a â â æ** and so on through all the variations available. The character variations and the order in which the variations appear depend on the language you have selected to use.

Adding Symbols

The printer supports the extended symbol set as shown in Figure 9.

A	!	ı	?	¿	.
B	,	'	#	%	&
C	;	"	+	=	*
D	-	:	/	()
E	~	\	@	±	½
F	\$	£	¢	\$	¼
G	↓	↑	→	←	—
H					
I					
J					
K					
L					
M					
N					
O					

Figure 9

To add a symbol

1. Press + . The first row of symbols shown in Figure 9 is displayed.
2. Use the arrow keys to move to the desired symbol. You can move horizontally and vertically through the rows of symbols.
3. When you locate the symbol, press to add the symbol to your label.

Saving your Label

You can save up to 25 labels in memory.

To save a label

1. Type your label text.
2. Press + to display the memory locations. Each memory location is identified by a number (01, 02 ... 25). If a memory location contains a saved label, the label content is displayed next to the number.
3. Use the arrow keys to select an empty location.
4. Press to save the label.

Recalling from Memory

Once a label is saved to memory, you can recall the label to print or edit.

To recall a label from memory

1. Press . The memory locations are displayed.
2. Use the arrow keys to find the memory location for the label you want and then press .