

Easy to set up

Maestro Wireless products can be set up quickly and easily.

Step 1

Press and hold the dimmer or switch tap button for approximately six seconds. Once the LED(s) starts to blink slowly, release the tap button.



Step 2


Press and hold the "off" button on the Pico™ wireless control or sensor for approximately six seconds. When the dimmer or switch learns the Pico wireless control or sensor, its LED and load will flash three times and the device will exit setup mode.



Repeat steps 1 and 2 to set up multiple Pico wireless controls or sensors to a single dimmer.
Repeat steps 1 and 2 to set up a single Pico wireless control or sensor to multiple dimmers.

Easy to use

The Pico™ wireless control and Maestro Wireless dimmer are easy for any homeowner to use.



LEDs indicate light level and glow softly so you can find the dimmer in the dark

rocker adjusts light level to suit any activity

tap once to turn lights on to favorite level, tap twice for full on, press and hold for delayed fade-to-off

